

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A1	2011 >	8X	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			1E Media player position 2	√	√	√	√
36 Driver`s side seat adj.	√	√	√	√			
37 Navigation	√	√	√	√			
3C Lane Departure Assistance System	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A2	2000 > 2005	8Z	16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			46 Central Control Module	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
A3/S3	1997 > 2003	8L	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			22 4WD Electronics	√	√	√	√
			35 Central Locking	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			55 Headlight range control	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
A3/S3/RS3/Cabrio	2004 > 2013	8P	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			22 4WD Electronics	√	√	√	√
			25 Immobilizer	√	√	√	√
			26 Electric roof control	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
42 DRIVER-DOOR ELECT.	√	√	√	√			
44 Steering assistance	√	√	√	√			
46 Central Control Module	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			7D Auxiliary Heater	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			22 4WD Electronics	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A3/S3/Cabrio NAR	2010 > 2013	FM	25 Immobilizer	√	√	√	√
			26 Electric roof control	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			44 Steering assistance	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
7D Auxiliary Heater	√	√	√	√			
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A3/S3/Cabrio	2013 >	8V	0F Radio Tuner-Digital	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			22 4WD Electronics	√	√	√	√
			25 Immobilizer	√	√	√	√
			26 Electric roof control	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			44 Steering assistance	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
69 TRAILER FUNCTION	√	√	√	√			
72 RR-DOOR ELECTRONI.	√	√	√	√			
76 Parking aid	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			77 TELEPHONE	√	√	√	√
			7D Auxiliary Heater	√	√	√	√
80/S2 B4	1992 > 1996	8C	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			25 Immobilizer	√	√	√	√
A4 B5	1995 > 2001	8D	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			25 Immobilizer	√	√	√	√
			35 Central Locking	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
67 VOICE CONTROL	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A4 B6/B7	2001 > 2008	8E	75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			46 Central Control Module	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
57 TV-TUNER	√	√	√	√			
65 Tyre pressure monitoring	√	√	√	√			
67 VOICE CONTROL	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			69 TRAILER FUNCTION	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A4 B8	2008 >	8K	1E Media player position 2	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
72 RR-DOOR ELECTRONI.	√	√	√	√			
77 TELEPHONE	√	√	√	√			
			01 Engine electronics	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A4 B8 NAR	2010 >	FL	02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			1E Media player position 2	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
37 Navigation	√	√	√	√			
3C Lane Departure Assistance System	√	√	√	√			
3D Special Function	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			77 TELEPHONE	√	√	√	√
Cabrio B4	1992 > 2000	8G	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			25 Immobilizer	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			26 Electric roof control	√	√	√	√
			35 Central Locking	√	√	√	√
Cabrio B6/B7	2003 > 2009	8H	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			26 Electric roof control	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			46 Central Control Module	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
57 TV-TUNER	√	√	√	√			
63 DRVS BOARDING ASS1	√	√	√	√			
65 Tyre pressure monitoring	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			67 VOICE CONTROL	√	√	√	√
			73 DRVS BOARDING ASS2	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
TT	1999 > 2007	8N	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			22 4WD Electronics	√	√	√	√
			35 Central Locking	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			76 Parking aid	√	√	√	√
77 TELEPHONE	√	√	√	√			
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
TT/TTS/TTRS	2007 >	8J	09 Electronic Ctrl Electronics	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			22 4WD Electronics	√	√	√	√
			25 Immobilizer	√	√	√	√
			26 Electric roof control	√	√	√	√
			37 Navigation	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			44 Steering assistance	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
76 Parking aid	√	√	√	√			
77 TELEPHONE	√	√	√	√			
7D Auxiliary Heater	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
TT/TTRS NAR	2010 >	FK	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			22 4WD Electronics	√	√	√	√
			25 Immobilizer	√	√	√	√
			26 Electric roof control	√	√	√	√
			37 Navigation	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			44 Steering assistance	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
4C Tyre Pressure Monitor II	√	√	√	√			
52 PASSE.-DOOR ELECT.	√	√	√	√			
55 Headlight range control	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			56 Radio	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			7D Auxiliary Heater	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A5/S5/RS5	2008 >	8T	1E Media player position 2	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A5/S5/RS5 NAR	2010 >	FH	05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			1E Media player position 2	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A5/S5/RS5 Cab	2009 >	8F	10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			1E Media player position 2	√	√	√	√
			26 Electric roof control	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
55 Headlight range control	√	√	√	√			
56 Radio	√	√	√	√			
57 TV-TUNER	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			5C Lane Keeping Assistance System	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A5/S5 Cab NAR	2010 >	FR	18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			1E Media player position 2	√	√	√	√
			26 Electric roof control	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
69 TRAILER FUNCTION	√	√	√	√			
6C Rear Camera	√	√	√	√			
6D Electronic Equipment of Trunk Lid	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			77 TELEPHONE	√	√	√	√
100/200 C3	> 1991	44	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			25 Immobilizer	√	√	√	√
100/A6 C4	1992 > 1997	4A	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			25 Immobilizer	√	√	√	√
			35 Central Locking	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A6 C5	1998 > 2006	4B	18 Aux heating	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			35 Central Locking	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A6 C6	2005 > 2011	4F	0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			4F Electronic central electric II	√	√	√	√
52 PASSE.-DOOR ELECT.	√	√	√	√			
53 Parking Brake	√	√	√	√			
55 Headlight range control	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A6 C6 NAR	2010 > 2011	FB	13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
55 Headlight range control	√	√	√	√			
56 Radio	√	√	√	√			
57 TV-TUNER	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A6	2011 >	4G	16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
57 TV-TUNER	√	√	√	√			
5F Information Electronic Equipment 1	√	√	√	√			
61 Battery control	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A6 C7 NAR	2011 >	FC	18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
61 Battery control	√	√	√	√			
62 LR-DOOR ELECTRONI.	√	√	√	√			
65 Tyre pressure monitoring	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A7	2011 >	4G	1E Media player position 2	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
65 Tyre pressure monitoring	√	√	√	√			
67 VOICE CONTROL	√	√	√	√			
69 TRAILER FUNCTION	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A7 NAR	2011 >	FC	28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4C Tyre Pressure Monitor II	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
69 TRAILER FUNCTION	√	√	√	√			
6D Electronic Equipment of Trunk Lid	√	√	√	√			
72 RR-DOOR ELECTRONI.	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
A8 D2	1994 > 2003	4D	01 Engine electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			25 Immobilizer	√	√	√	√
			35 Central Locking	√	√	√	√
			37 Navigation	√	√	√	√
			45 Interior Monitoring	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
75 Emergency call module	√	√	√	√			
76 Parking aid	√	√	√	√			
77 TELEPHONE	√	√	√	√			
			02 Transmission Electronics	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1D Driver identification	√	√	√	√
			1E Media player position 2	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A8 D3	2003 > 2010	4E	38 ROOF ELECTRONICS	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4E Control head RR	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5E Control head LR	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			66 Seat-/mirror adjust.	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
72 RR-DOOR ELECTRONI.	√	√	√	√			
75 Emergency call module	√	√	√	√			
76 Parking aid	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1D Driver identification	√	√	√	√
			1E Media player position 2	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A8 D3 NAR	2010	FA	37 Navigation	√	√	√	√
			38 ROOF ELECTRONICS	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4E Control head RR	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5E Control head LR	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			66 Seat-/mirror adjust.	√	√	√	√
67 VOICE CONTROL	√	√	√	√			
69 TRAILER FUNCTION	√	√	√	√			
6C Rear Camera	√	√	√	√			
72 RR-DOOR ELECTRONI.	√	√	√	√			
75 Emergency call module	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1D Driver identification	√	√	√	√
			1E Media player position 2	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A8 D4	2010 >	4H	36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			38 ROOF ELECTRONICS	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4E Control head RR	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5E Control head LR	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			66 Seat-/mirror adjust.	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
69 TRAILER FUNCTION	√	√	√	√			
6C Rear Camera	√	√	√	√			
72 RR-DOOR ELECTRONI.	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1D Driver identification	√	√	√	√
			1E Media player position 2	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
A8 D4 NAR	2010 >	FD	34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			38 ROOF ELECTRONICS	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4E Control head RR	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5E Control head LR	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			66 Seat-/mirror adjust.	√	√	√	√
67 VOICE CONTROL	√	√	√	√			
69 TRAILER FUNCTION	√	√	√	√			
6C Rear Camera	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			72 RR-DOOR ELECTRONI.	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1D Driver identification	√	√	√	√
			1E Media player position 2	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
Q3	2012 >	8U	28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			38 ROOF ELECTRONICS	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4E Control head RR	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5E Control head LR	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
66 Seat-/mirror adjust.	√	√	√	√			
67 VOICE CONTROL	√	√	√	√			
69 TRAILER FUNCTION	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			6C Rear Camera	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			75 Emergency call module	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
Q5	2009 >	8R	22 4WD Electronics	√	√	√	√
			2E Media player position 3	√	√	√	√
			30 Special Function 2	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
6C Rear Camera	√	√	√	√			
6D Electronic Equipment of Trunk Lid	√	√	√	√			
72 RR-DOOR ELECTRONI.	√	√	√	√			
77 TELEPHONE	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
Q5 NAR	2010 >	FP	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			10 Parking Assist System 2	√	√	√	√
			13 Distance control	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1B Power-Assisted Steering	√	√	√	√
			20 High Beam Assistance Device	√	√	√	√
			22 4WD Electronics	√	√	√	√
			2E Media player position 3	√	√	√	√
			30 Special Function 2	√	√	√	√
36 Driver`s side seat adj.	√	√	√	√			
3C Lane Departure Assistance System	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			3D Special Function	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			53 Parking Brake	√	√	√	√
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			5F Information Electronic Equipment 1	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
Q7	2007 >	4L	07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
47 Soundsystem	√	√	√	√			
4F Electronic central electric II	√	√	√	√			
52 PASSE.-DOOR ELECT.	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			55 Headlight range control	√	√	√	√
			56 Radio	√	√	√	√
			57 TV-TUNER	√	√	√	√
			5C Lane Keeping Assistance System	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			6F Confort Central Control Unit II	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			05 ACCESS & PERMISSI.	√	√	√	√
			06 PASSENE. SEAT ADJ.	√	√	√	√
			07 DISPLAY-/CNTL UNIT	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
Q7 NAR	2010 >	FE	0E Media player position 1	√	√	√	√
			0F Radio Tuner-Digital	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			13 Distance control	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			18 Aux heating	√	√	√	√
			19 Gateway data bus	√	√	√	√
			1E Media player position 2	√	√	√	√
			28 Climate Control Unit Rear	√	√	√	√
			34 Self leveling suspension	√	√	√	√
			36 Driver`s side seat adj.	√	√	√	√
			37 Navigation	√	√	√	√
			3C Lane Departure Assistance System	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			4F Electronic central electric II	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
55 Headlight range control	√	√	√	√			
56 Radio	√	√	√	√			
57 TV-TUNER	√	√	√	√			

Audi V11.11 Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			5C Lane Keeping Assistance System	√	√	√	√
			61 Battery control	√	√	√	√
			62 LR-DOOR ELECTRONI.	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			67 VOICE CONTROL	√	√	√	√
			69 TRAILER FUNCTION	√	√	√	√
			6C Rear Camera	√	√	√	√
			6D Electronic Equipment of Trunk Lid	√	√	√	√
			6F Confort Central Control Unit II	√	√	√	√
			72 RR-DOOR ELECTRONI.	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
			01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			19 Gateway data bus	√	√	√	√

RR

2007 >

12

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
no	2007 <	44	25 Immobilizer	√	√	√	√
			37 Navigation	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			56 Radio	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			6C Rear Camera	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√
R8 NAR	2010 >	FG	01 Engine electronics	√	√	√	√
			02 Transmission Electronics	√	√	√	√
			03 Brake Electronics	√	√	√	√
			08 AC/Heating electronics	√	√	√	√
			09 Electronic Ctrl Electronics	√	√	√	√
			11 Engine electronics 2	√	√	√	√
			14 Wheel damping electronics	√	√	√	√
			15 Airbags	√	√	√	√
			16 Steering Wheel Electronics	√	√	√	√
			17 Instrument Cluster	√	√	√	√
			19 Gateway data bus	√	√	√	√
25 Immobilizer	√	√	√	√			

Audi **V11.11** Diagnostics List(Note:For reference only)

MODEL	YEAR	TYPE	SYSTEM	Functions			
				Sys. Info.	Read code	Clear code	Data Stream
			37 Navigation	√	√	√	√
			42 DRIVER-DOOR ELECT.	√	√	√	√
			46 Central Control Module	√	√	√	√
			47 Soundsystem	√	√	√	√
			52 PASSE.-DOOR ELECT.	√	√	√	√
			56 Radio	√	√	√	√
			65 Tyre pressure monitoring	√	√	√	√
			6C Rear Camera	√	√	√	√
			76 Parking aid	√	√	√	√
			77 TELEPHONE	√	√	√	√